

POCKET 4

TOWER Q  
(S+7)

TOWER R  
(S+8)

TOWER P  
(S+13)

TOWER O  
(S+13)

TOWER N  
(S+18)

TOWER L  
(S+19)

TOWER M  
(S+19)

TOWER K  
(S+19)

TOWER J  
(S+20)

CLUB

POCKET 3

TOWER H  
(S+23)

TOWER F  
(S+23)

TOWER G  
(S+23)

POCKET 2

TOWER D  
(S+23)

TOWER E  
(S+23)

POCKET 1

TOWER C  
(S+18)

TOWER A  
(S+18)

TOWER B  
(S+19)

